

NOR810 dB+

Adjustment Guide



The aluminium threshold supplied must be cut to length and fitted after frame has been installed. It must not be installed under the frame.

Ideally the gap between the bottom of the door and the top of the threshold should be 10mm. If greater than 15mm the drop seal may not close the gap.

Gently close the door whilst carefully observing the action of the seal at the door bottom.

The NOR810dB+ will require adjustment if it either:-

- a) Snags on the floor during closing
- or
- b) Does not contact the threshold once the door is fully latched.

To adjust the seal travel :-

- Pull out the adjustment nut until it is clear of the aluminium housing.
- Turn the nut clockwise to reduce or anti-clockwise to increase the overall seal drop (shown opposite).

Please note the drop seal is self-levelling. If the NOR810dB+ is adjusted correctly, one end of the seal will drop first followed by the rest of the seal. Please turn the adjustment nut anti-clockwise until the full length of the seal contacts the threshold.

NOTE - It is **not** necessary to **completely** compress the silicone seal.

As a final check to ensure the seal is adjusted correctly, place these adjustment instructions flat on the threshold or floor. With the door closed, the seal should just grip the paper.

